

Cleaning Guide and Routine Maintenance

Periodically inspect all fasteners on the Interpreter on Wheels™ (IOW) Stand and Enclosure. Tighten as necessary for optimal operation and safety.

Cleaning the Interpreter on Wheels™ Stand and Enclosure

1. The IOW and Enclosure may be cleaned with most mild, non-abrasive solutions commonly used in the hospital environment (diluted bleach, ammonia, or alcohol solutions).
2. The surface finish will be permanently damaged by strong chemicals and solvents, such as acetone and trichloroethylene.
3. Do not use steel wool or other abrasive material to clean the IOW and Enclosure.
4. Damage caused by the use of unapproved substances or processes will not be covered by warranty. We recommend that you test any cleaning solution on a small area of the IOW and Enclosure that is not visible to verify compatibility.
5. Never submerge or allow liquids to enter the IOW or Enclosure. Wipe any cleaning agents off the IOW and Enclosure immediately using a water-dampened cloth. Dry all surfaces thoroughly after cleaning. **NOTE: The exception to this is the front of the Enclosure, which can be removed and submerged for cleaning.**

DISCLAIMER: LanguageLine Solutions® and ArmorActive make no claims regarding the efficacy of the listed chemicals or processes as a means for controlling infection. Consult your hospital's infection control officer or epidemiologist. To clean or sterilize mounted instruments or accessory equipment, refer to the specific instructions delivered with those products.

The following specified cleaning chemicals (typically found in a medical environment) will not degrade or discolor the product.

NOTE: When not using premoistened wipes, spray the product onto a cloth or paper towel prior to applying it to the equipment.

<p>DisCide Wipes</p> 	<p>CaviWipes</p> 	<p>Sani-Cloth HB</p> 	<p>Sani-Cloth Plus</p> 	<p>Super Sani-Cloth</p> 
<p>Clorox Bleach (10%) Wipes</p> 	<p>Virex 256</p> 	<p>409 Glass and Surface Cleaner</p> 	<p>Windex Blue</p> 	<p>Isopropyl Alcohol Wipes (70%)</p> 

QUESTIONS? Please contact your LanguageLine Solutions® Account Executive.